## Release Notes for DrayTek Vigor 167 (UK/Ireland)

Firmware Version	5.1.1_BT (Formal Release)
Release Type	Initial Release
Build Date	3 <sup>rd</sup> May 2022
Release Date	25 <sup>th</sup> May 2022
Revision	5.1.1, Web: 3.3.2, Core: DrayOS5_5
Applicable Models	Vigor 167
Modem Code	5.12.18.16
Locale	UK & Ireland Only

First Firmware Release for this model

For more UK product details & specification, please visit <a href="https://www.draytek.co.uk">https://www.draytek.co.uk</a>

See <a href="https://www.draytek.co.uk/support/product-knowledgebase">https://www.draytek.co.uk/support/product-knowledgebase</a> for Vigor 167 setup examples.


## **Firmware File Types**

The ZIP file contains the firmware with two different file extensions, .ALL and .RST. The firmware is identical, but the RST file contains factory default settings. If you install the ALL file, your modem will retain all existing settings. If you use the RST file, <u>all settings will be wiped from your modem</u>.

## **Upgrade Instructions**

It is recommended that you take a configuration backup prior to upgrading the firmware. This can be done from the modem's system maintenance menu.

To upgrade firmware, select 'Firmware' from the modem's system maintenance menu and select the correct file. Ensure that you select the ALL file <u>unless</u> you want to wipe out your modem's settings back to factory default.



## **Manual Upgrade**

If you cannot access the modem's menu, you can put the modem into 'TFTP' mode by holding the RESET whilst turning the unit on and then use the Firmware Utility. That will enable TFTP mode. TFTP mode is indicated by all LEDs flashing. This mode will also be automatically enabled by the modem if there is a firmware/settings abnormality. Upgrading from the web interface is easier and recommended – this manual mode is only needed if the web interface is inaccessible.